

Remove the depleted battery using a small flathead screw-driver.

Insert a new battery with the "+" terminal facing up.

- Use a CR2016 (vehicles without a smart key system) or CR2032 (vehicles with a smart key system) lithium battery
  - Batteries can be purchased at your Toyota dealer, local electrical appliance shops or camera stores.
  - Replace only with the same or equivalent type recommended by the manufacturer.
  - Dispose of used batteries according to local laws.
- If the key battery is depleted

The following symptoms may occur:

- The smart key system and wireless remote control will not function properly.
- The operational range will be reduced.

## **A** CAUTION

## Removed battery and other parts

Keep away from children. These parts are small and if swallowed by a child, they can cause choking. Failure to do so could result in death or serious injury.